



IODE Canada

T-SHIRT DECAL INSTRUCTIONS

Do not remove transfer until it is completely cool.

- 1) Print decal onto paper to ensure proper fit to the transfer.
- 2) Set the iron to the highest cotton setting (MAKE SURE THERE IS NO WATER IN THE IRON TO PRODUCE STEAM) and preheat 5 minutes. For best results, lay a pillowcase on a firm, hard surface such as a counter or tabletop to iron your transfer. DO NOT USE AN IRONING BOARD as the surface is too soft and may not be sturdy enough when ironing your transfer.
- 3) Garment to receive the transfer should be 100% cotton. Place your garment on the pillowcase and iron it to remove wrinkles.
- 4) When garment is completely cool, lay it on a hard, smooth surface. Position your transfer image face down (Staples logo facing up) on the surface.
- 5) Using FIRM PRESSURE, hold the iron with both hands and iron each area of the sheet for 15-20 seconds, making sure to lift the iron completely when moving to a new position. Be sure to cover all corners and edges of the sheet.
- 6) Using FIRM PRESSURE, hold the iron with both hands to apply firm, downward pressure for an **additional 2 ½ minutes**. Iron with a consistent circular motion making sure to completely cover your design. Note: Make sure to iron over all edges and corners to prevent design from lifting or wrinkling.
- 7) When **garment is completely cool**, peel paper from back of transfer using firm, steady pressure. To facilitate peeling, gently fold the fabric near an edge of the transferred image.

Note: Do not re-iron over any image once the backing paper has been removed.

Washing instructions:

- 1) Turn garment inside out.
- 2) Wash garment separately from other (first time only).
- 3) Machine wash in cold water with colour-safe detergent (no chlorine bleach).
- 4) Remove promptly from washing machine. Colours may bleed if left wet too long. If bleeding occurs, re-wash immediately.
- 5) Tumble dry medium.